

GETTING STARTED | THE ALTAIR io ECOSYSTEM



STEP 1

GRID WEB APP

1. Log in to the MSA Grid web app.
2. Don't have an account? Contact MSA.
3. Using the Grid web app, set up your customer ALTAIR io 4 cloud-configuration profile under the Assets > Configuration tab. The factory default is used otherwise.
4. Set up your workforce roster on the labels tab.



STEP 2

GRID MOBILE APP

1. Download the Grid mobile app from Google Play or Apple App Store.
2. Log into your MSA Grid account.



STEP 3

ALTAIR io 4

1. Devices arrive pre-commissioned to your account under your default configuration. Turn devices on, and, each device will show up as connected and your default configuration applied.



STEP 4

MSA ID TAG

1. In your Grid mobile app, use the guided Tag setup to assign an MSA id tag to a worker from your created roster.
Note: You can create tags to de-assign units from workers OR, simply put the unit in the ALTAIR io CHARGE to de-assign.
2. **Optional:** You can now take your newly create ID tags, and assign them to your devices if you wish to do so.



STEP 5

ALTAIR io DOCK

1. Assemble your bank (including cylinder holder) and plug it into power.
2. Use the Grid mobile app's guided DOCK setup.
Note: Make sure you're connected to the bank's primary test stand, located farthest to the right.
3. Configure your bank's settings – including giving it a unique identifier used in your Grid account.



STEP 6

ALTAIR io CHARGE

1. Run power to the ALTAIR io Charge.
2. Use the Grid mobile app's guided Charge setup.
3. Make sure to give it a unique identifier which will be used in your Grid account.